

**E-Z-GO Outlaw Bar
Installation Instructions
Black- Part# 6242
Gunmetal- Part# 7080
Stainless- Part# 6246**



****NOTE-This bar only fits E-Z-GO models lifted with Jake's Long Travel Lift Kit****

Parts List

- Outlaw Bar-1*
- 1/4 x 1 3/4 Bolts-2*
- 1/4 Locknuts-2*



JAKE'S



*Always wear appropriate
eye protection!*

1. If you already have a front bumper mounted to the Jake's Long Travel Lift Kit remove it.
2. With the supplied bolts and lock nuts mount the Jake's Outlaw Bar to the long travel main frame as shown.
3. Securely tighten all bolts.



866-405-2537

www.jakesliftkits.com