VOLT-0001 Installation Instructions

- 1. Connect the fused positive feed of your 12 Volt accessory to the Positive (+) Post of Battery #1
- 2. Connect the 8 Gauge wire from VOLT-0001 to the Negative (-) Post of Battery #2
- 3. Connect the -12 Ground from your Accessory to the VOLT-0001 lead with two 14 gauge wires. If you are only using one accessory, tape off and isolate the second lead.

